

Table of Contents

- **Procedure No. 1** (8/5/09)
Job Safety Briefing
- **Procedure No. 2** (5/30/12)
Cover Up Procedures
- **Procedure No. 3** (5/30/12)
Barricading of Aerial Lift and Derrick Truck Equipment
- **Procedure No. 4** (5/30/12)
Tree Cutting
- **Procedure No. 5** (5/30/12)
Qualified Observer
- **Procedure No. 6** (5/30/12)
Load and Unload Poles
- **Procedure No. 7** (5/30/12)
Replacing Poles in Energized Lines
- **Procedure No. 8** (5/30/12)
Working from an Insulated Work Surface (Hot Board) Using the Insulated
Gloves Method
- **Procedure No. 9** (5/30/12)
Working Primary Underground and URD Facilities
- **Procedure No. 10** (5/30/12)
Maintenance of Hot Sticks
- **Procedure No. 11** (5/30/12)
Load Break Tool Use
- **Procedure No. 12** (5/30/12)
Phasing Circuits
- **Procedure No. 13** (5/30/12)
Gang Operated Air Break Switch Operation
- **Procedure No. 14** (5/30/12)
Non-Reclose Orders
- **Procedure No. 15** (5/30/12)
Ladder Setup
- **Procedure No. 16** (5/30/12)
Performing Installation and Repair Work on Service Equipment
- **Procedure No. 17** (5/30/12)
De-energizing, Testing and Grounding Facilities when Replacing Broken
Poles
- **Procedure No. 18** (5/30/12)
Use of Flame Retardant Clothing
- **Procedure No. 19** (5/1/07)
Service Restoration
- **Procedure No. 20** (8/8/12)
Backing and Parking Vehicles to Avoid Accidents

Revised 5/30/12

Table of Contents (continued)

- **Procedure No. 21** (8/8/12)
Use of Mobile Electronic Devices (Attentive Driving)
- **Procedure No. 22** (5/30/12)
Working on De-energized and Grounded Lines
- **Procedure No. 23** (5/30/12)
Procedures for Gloving Lines Operated Above 15Kv
- **Procedure No. 24** (5/30/12)
Performing Dead Work beyond Line Cutouts
- **Procedure No. 25** (5/30/12)
Working on Lines Where the Primary Neutral is missing
- **Procedure No. 26** (5/30/12)
Performing Emergency Work on or Near Railroad R/W
- **Procedure No. 27** (5/30/12)
Station Circuit Breaker Operation
- **Procedure No. 28** (5/30/12)
Emergency Work Procedures for Handling Hazardous Conditions
- **Procedure No. 29** (5/30/12)
Transferring Dead Ended Conductors Over Roadways